



# LEE BROOM



## **CHAMBER**



#### ATTENTION

- WE SUGGEST THAT CHAMBER SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN.
- ENSURE POWER SUPPLY IS DISCONNECTED PRIOR TO INSTALLATION.
- THIS PRODUCT IS FOR INTERIOR USE ONLY AND SHOULD BE INSTALLED IN A DRY ENVIRONMENT.
- WHEN SWITCHED ON, CHAMBER MAY BECOME HOT.
- MINIMUM OF TWO PEOPLE REQUIRED FOR INSTALLATION.



40W MAXIMUM WATTAGE THIS
PRODUCT 220
MUST BE 50EARTHED

220/240V 50-60HZ E27 LAMP HOLDER

#### CARE AND CLEANING

- ONLY ATTEMPT TO CLEAN WHEN CHAMBER IS SWITCHED OFF.
- PLEASE ALLOW A SUITABLE COOLING PERIOD BEFORE ATTEMPTING TO CLEAN CHAMBER OR REPLACE THE BULB.
- ONLY USE A NON-ABRASIVE, SOFT, DRY CLOTH WHEN CLEANING CHAMBER.

### **ASSEMBLY**

- SEPARATE TOP PLATE FROM CEILING ROSE COVER BY REMOVING SCREWS.
- 2. TERMINATE ALL MAINS WIRES AT CONNECT POINT.
- 3. MOUNT THE BACK PLATE TO THE CEILING USING SUITABLE FIXINGS. ALWAYS USE APPROPRIATE FIXINGS FOR THE CEILING MATERIAL YOU ARE FIXING TO.
- 4. LOOSEN THE CABLE GRIP SCREW AND REMOVE PENDANT CABLE AWAY FROM CEILING ROSE.
- 5. THREAD THE PENDANT CABLE THROUGH THE CRYSTAL VESSEL.
- 6. THREAD THE PENDANT CABLE THROUGH THE CEILING ROSE AND ADJUST THE CABLE TO REQUIRED LENGTH.
- 7. TIGHTEN THE CABLE GRIP SCREW ONCE AT CORRECT LENGTH.
- 8. CONNECT EACH MAINS WIRE AND PENDANT WIRE INTO ITS CORRECT TERMINAL IN THE PROVIDED JUNCTION BOX.
- 9. ATTACH THE CEILING ROSE COVER TO THE BACK PLATE USING THE PROVIDED FOUR SCREWS.
- 10. FIT BULB INTO LAMP HOLDER (RECOMMENDED GOLF BALL BULB, MAX 40W).

